

Headset Cup removal and installation instructions

We have been asked many times how to remove an old headset and install a new one. These instructions tell you how to remove the old cups from the head tube of your scooter and install new ones. Please follow the instructions below to ensure proper installation of your new fork. Please refer to the pictures and video links below.

Remove the lock nut and threaded race from the top of the fork (there is no washer on the Razor), slide out the fork. Remove the bearing retainer from the upper and lower pressed races or cups.

Put the scooter on a solid surface where it has good support. Watch this YouTube video: <http://www.youtube.com/watch?v=jbO8PDrKdP0>

Once the old cups are out, clean the inside of the head tube where the new cups go and make sure they are smooth with no damage. Put some grease where the cups will go. Now watch this video: <http://www.youtube.com/watch?v=KEczBjf8aKI>

One cup at a time! You can make your own tool to press the cups in. Go to the hardware store and buy a foot long piece of $\frac{3}{4}$ inch threaded rod with two $\frac{3}{4}$ nuts and two (4 is better) thick and large washers, large enough to cover the entire cup. Make sure you have a wrench large enough to turn the nuts because it will need some force.

